

The OVIRS Visible/IR Spectrometer on the OSIRIS-Rex Mission

International Workshop on Instrumentation for
Planetary Missions

October 11, 2012

Dennis Reuter and Amy Simon-Miller

GSFC Code 693

301-286-2042


dennis.c.reuter@nasa.gov

OSIRIS-REx

- Origins Spectral Interpretation Resource Identification Security Regolith Explorer
 - Third New Frontiers mission
- Sample return from asteroid 1999 RQ36
 - Primitive B-type carbonaceous asteroid, a class that has never been studied up close
- Scheduled for launch in Sept 2016

INSTRUMENTS SUPPORT SAMPLE RETURN BUT ALSO ENHANCE SCIENCE

- **OSIRIS-REx Camera Suite (*OCAMS*)**
 - (UA): Provides long-range acquisition of RQ36, along with global mapping, sample-site characterization, sample acquisition documentation, and sub-cm imaging
- **OSIRIS-REx Visible and IR Spectrometer (OVIRS)**
 - (GSFC): Provides mineral and organic spectral maps and local spectral information of candidate sample sites from 0.4 - 4.3 μm
- **OSIRIS-REx Thermal Emission Spectrometer (OTES)**
 - (ASU): Provides mineral and thermal emission spectral maps and local spectral information of candidate sample sites from 4 - 50 μm
- **OSIRIS-REx Laser Altimeter (OLA)**
 - (CSA): Provides ranging data; global topographic mapping; and local topographic maps of candidate sample sites




OVIRS CONCEPT OVERVIEW

- Visible-Near IR Spot Spectrometer
- Use Linear Variable Filter (LVF) approach
 - 2-D filter in which the pass-band wavelength varies in 1 dimension
 - Filter placed directly over 2-D array
 - Spectral resolution and band optimized for application
- Spectrometer builds on flight heritage of New Horizons Ralph/LEISA instrument
 - Passive cooling
 - Aluminum Structure and Mirrors for Athermal Design
- Simple 2-Mirror Optical System
 - Afocal focal plane


OVIRS DESIGN OVERVIEW

- Passively-cooled point spectrometer (0.4 to 4.3-microns)
 - Optical design draws from New Horizons Ralph (LEISA). Similar design and layout, but simplified
 - HIRG detector heritage: HST WFC3, OCO, WISE
 - Only require 512 x 512 quadrant, uses WISE 4.2- μm cutoff array substrate removed HgCdTe
 - SIDECAR ASIC: GSFC experience with JWST, HST ACS, LDCM TIRS
 - 4-millirad FOV
 - Easily modified for 1 – 2 milliradian
 - 2-meter surface resolution @ 0.5-km altitude sample site reconnaissance phase
 - Four linear variable filter segments (baseline, will be tuned after contract awarded)
 - 0.4 to 0.9 μm : resolving power ($\lambda/\Delta\lambda$) = 125 (max 7-nm resolution, 200 cm^{-1} @ 0.4 μm)
 - 0.9 to 2.0 μm with resolving power = 150 (max 13-nm resolution, 75 cm^{-1} @ 0.9 μm)
 - 2.0 to 4.3 μm with resolving power = 200 (max 22-nm resolution, 25 cm^{-1} @ 2.0 μm)
 - 2.9 to 3.6 μm with resolving power = 350 (max 10-nm resolution, 10 cm^{-1} @ 2.9 μm)
- Operations/Modes:
 - On (14 W)
 - Decontamination (20 W for decon heaters)
 - Calibration (+2 W for cal lamps)
 - Off (5 W for survival heaters)


FUNCTIONAL BLOCK DIAGRAM




OVIRS MAIN ELECTRONICS BOX (MEB)





OVIRS OPTICS BOX



OVIRS INTERNAL VIEW




EXTREMELY SIMPLE OPTICAL DESIGN




- **1 AU Heliocentric Distance**
- **Close Proximity of Spacecraft**
- **Allows trade of efficiency for simplicity**
- **Example: New Horizons LEISA focal plane**

OVIRS Beam Path




INSTRUMENT SUITE LAYOUT




OVIRS ENHANCES SAMPLE RETURN SCIENCE

From approach to sample site characterization (144-km to 30-m range), OVIRS:

- Obtains 0.4 to 4.3- μm spectra, diagnostic for mineralogy and organics
 - Produces, with OTES, unprecedented global visible/IR surface inventory
 - Provides geological context for returned sample
 - Documents scale of surface variability
 - Characterizes space weathering and impact history
 - Constrains Yarkovsky effect thermal emission and solar reflection contributions
- Informs choice of sample site selection and provides context
- Provides connection between ground-based observations and *in-situ* measurements



SPECTRA DEPEND ON REFLECTION AND EMISSION



IN-HOUSE I&T AND CALIBRATION REDUCES RISK



The Detector Characterization Laboratory (DCL) – Focal plane testing and characterization



EMI/EMC Test chamber



GSFC Vibration test facility in Building 7



Visible/ Infrared in-chamber NIST traceable calibration facility



Thermal/vacuum test facilities